

GETTING STARTED

REQUIRED SUPPLIES:

SPRING FLOOR KIT FOR INTENDED PROJECT INCLUDING:

- ✓ SPRINGS: 4" PALMER COIL SPRINGS
- ✓ CAPS: TOP MOUNTING CAP (Solid Core Center)
BOTTOM MOUNTING CAP (Hollow Core Center)
- ✓ HARDWARE: T-NUTS
MACHINE SCREWS
I/E LOCK WASHERS
- ✓ PLYWOOD: BOTTOM LAYER - 4'x 8'x 1/2" BCX PLYWOOD }
TOP LAYER - 4'x 8'x (1/2" BCX PLYWOOD) }
- ✓ VELCRO SUPPLIES (see Velcro Kit Instructions) OR DRYWALL
SCREWS FOR OVER LAYMENT

REQUIRED TOOLS:

- ✓ CIRCULAR SAW OR TABLE SAW (for cutting plywood)
- ✓ WORK HORSES (for stacking plywood)
- ✓ POWER DRILL
 - 1/4" drill bit
 - Phillips head bit
- ✓ MEASURING INSTRUMENTS TO MARK BOARDS
 - chalk string
 - tape measure
 - pencil or marker
- ✓ HAMMER
- ✓ POWER CORD/S