

Assembly Instructions

Air Pit & Bungee Products



①

To inflate your Air Pit or Bungee Product unscrew the cover and place a pump or shop-vac over the valve hole.

To make your Air Pit or Bungee Product softer or for slow deflation press the button in the valve.

②



For faster deflation twist the valve cap off and allow all the air to be released.

③



NOTE: If air is leaking from the valve, make sure the rubber stoppers are fully extended and not bent. (see photo to right)



Fully extended rubber stoppers

CAUTION

Any activity involving motion, rotation or height creates the possibility of serious injury including permanent paralysis and even death from landing or falling on the neck, head or other parts of the body. Gymnastic mats and floors cannot and do not eliminate this hazard entirely. You still assume a risk of serious injury when using this equipment.

Before each use, always check apparatus for damages or wear. If in doubt, do not use the product. This gymnastic apparatus can move during use. Always check for proper positioning of the product before use.

Attaching two Bungee Products, using the end flaps with Velcro



①

Place the two ends of your Bungee Products next to each other with the end flaps folded back (shown are 2 Bungee Blocks).

Fold over the flap with loop Velcro to cover the hook Velcro on the other Bungee Product.

②



③

Connect the flap from the second Bungee Product by repeating Step 2.

Enjoy your Bungee Products!

④



Tumbl Trak
Do It Again

NOTE: Tumbl Trak equipment is not recommended for the use in **Parkour/Free Running** related activities.